

ESCORT MK1/2 YB KIT- PARTS TO BE SUPPLIED.

1 X INTERCOOLER

1 X RADIATOR

2 X SPAL VA14-AP7/C-34A FANS

2 X FAN FIXING KITS

4 X M6 STAINLESS SHORT REACH BOLTS WITH WASHERS (FOR BOLTING RADIATOR TO INTERCOOLER).

2 X M6 STAINLESS BOLTS WITH WASHERS (FOR BOLTING THROUGH SLAM PANEL INTO BRACKETS LOCATED ON INTERCOOLER)

3 X SELF TAPPING SCREWS (FOR MOUNTING THROUGH LOWER PLATE OF INTERCOOLER)

RADTEC RACING RADIATORS LTD

INSTRUCTION GUIDE MK1/2 ESCORT YB KIT

1. REMOVE RADIATOR AND ANY INSTALLED ITEMS IN FRONT ENGINE BAY OF CAR.
2. THIS SHOULD LEAVE THE RADIATOR FIXING FLANGES EXPOSED.
3. REMOVE RADIATOR FIXING FLANGES FROM ENGINE BAY, LEAVING A SQUARE OPENING AT THE FRONT OF THE CAR.
4. SLIDE INTERCOOLER INTO OPENING SO IT ENDS UP BEING THE FIRST ITEM YOU SEE WHEN LOOKING AT THE FRONT OF THE CAR.THE INTERCOOLER SHOULD BE PUSHED FAR ENOUGH BACK SO THE LOWERPLATE ENDS UP AGAINST THE BOTTOM PANEL
5. DRILL TWO HOLES INTO TOP SLAM PANEL LINNING UP WITH M6 THREADED RIVNUTS FITTED TO TOP SIDE FRAME OF INTERCOOLER.
6. DRILL HOLES IN LOWER INTERCOOLER PLATE AND FIT SELF TAPPING SCREWS TO BOTTOM PANEL TO SECURE INTERCOOLER IN PLACE.
7. FIT RADIATOR TO INTERCOOLER USING BRACKETS AND BOLTS PROVIDED
8. KNOW OFFER TWIN FANS INTO BEST POSITION ON THE ENGINE SIDE OF THE RADIATOR SO THEY ARE DRAWING THE AIR THROUGH. DRAW ROUND FANS WHERE REQUIRED.
9. REMOVE RADIATOR AND FIX FANS USING KITS PROVIDED INTO POSITION MARKED
10. RE-FIT RADIATOR AND FANS COMBINED AS BEFORE.
11. IF YOU FEEL DETAIL IS MISSING FROM THIS GUIDE THAT YOU FEEL SHOULD BE ADDED PLEASE RING RADTEC ON 01543-502525 AS YOUR INPUT WOULD BE GRATELY APPRECIATED.



RADTEC

Racing Radiators